# ReaSnow S1 Quick Guide

1. Upgrade ReaSnow S1 by "ReaSnow Flash Tool.exe"

1.1. Plug ReaSnow S1 into PC while holding the button on it,
Release the button when ReaSnow S1 LED indicator is green.

1.2. Run "ReaSnow Flash Tool.exe" and click "Upgrade firmware" button.
Wait until the upgrade is finished.

2. Manage ReaSnow S1

2.1. Connect all your peripherals to ReaSnow S1,
then connect ReaSnow S1 to console.

As showed below：

● Go to PS1 for more wiring diagrams

2.2. Turn on Bluetooth and Location Serivces on your smart phone.
Then run **ReaSnow Manager APP**

Android: Search "ReaSnow Manager" in Google Play
                Or Download APK from our forum
iOS: Search "ReaSnow Manager" in App Store

PS1: Wiring Diagrams:

PS4 Pro/PS4 Slim/PS4/PS3
Xbox One X/Xbox One S/Xbox One/Xbox 360

Nintendo Switch